


Internet Sounds



OBJECTIVE: To show how to use a Photon and Tinker to turn trigger different sounds from your smartphone.

Parts List

Quantity	ID	Name	Part #
1		Base Grid Base Grid (11 x 7.7)	6SCBG
1		3-snap wire	6SC03
1	SP	Speaker	6SCSP
1	U2	Alarm IC	6SCU2
5		Snap-to-Pin wire (red, black, green, white and yellow)	SCJW10

Step by Step Guide

- 1) Snap the four corners of the component **U1** at **C2, D2, C4** and **D4** (see diagram for correct orientation)
- 2) Snap component **SP** between **B6** and **D6**
- 3) Connect a 3 snap wire between **D4** and **D6**
- 4) Connect the snap end of a **black** wire onto the component at position **D2**
- 5) Plug the bread board end of the **black** wire from step 4 into **GND** on the Photon in the breadboard
- 6) Connect the snap end of a **yellow** wire onto the component at position **C2**
- 7) Plug the bread board end of the **yellow** wire from step 6 into pin **D2** on the Photon in the breadboard
- 8) Connect the snap end of a **white** wire onto the component at position **C3**
- 9) Plug the bread board end of the white wire from step 8 into pin **D3** on the Photon in the breadboard
- 10) Connect the snap end of a **green** wire onto the component at position **C4**
- 11) Plug the bread board end of the **white** wire from step 10 into pin **D4** on the Photon in the breadboard
- 12) Connect your Photon to your power source

Step by Step Guide (continued)

- 14) Choose Get Started and select your Photon board in the UI
- 15) Open the Tinker application on your smartphone
- 16) Click the **D2** button and select **digitalWrite**
- 17) Click the **D3** button and select **digitalWrite**
- 18) Click the **D4** button and select **digitalWrite**
- 19) No vary the three pins, D2, D3 and D4 between HIGH and LOW to create different sounds